

# Electric conveyor manual

## SAFETY

- 1, Operated by professional person.
- 2, Before using, it is necessary to check whether all components are securely connected to avoid the risk of overturning.
- 3, During the operation of the conveyor belt, keep a safe distance.
- 4, Operators should be equipped with necessary safety protective equipment, such as safety helmets, goggles, and noise reduction earplugs.
- 5, Maintenance is carried out by professional person.

## NAME:

ELECTRIC BELT CONVEYOR



## MODEL:

LR-CVE650-6000

## TECH DATA:

- a) BELT WIDTH: 650 mm
- b) LENGTH: 6 meters
- c) WEIGHT: 550 kg
- d) BELT: 3+1.5
- e) POWER: Electric motor

## DIMENSIONS:



## HOW TO INSTALL CHUTE (IF HAS)



## OPERATION INSTRUCTIONS

- 1, Place the conveyor properly on a level ground and maintain stability.
- 2, Connected to a generator or city power grid, Please Note this conveyor driven by 220 Volt single phase.
- 3, The green indicator light is on, turn the right knob clockwise to start the conveyor, Turn the knob counterclockwise to stop the conveyor

